

Installation Notes:

1. Mounting frame: the column is connected with the beam, pay attention to the direction of the column, and fix it with M8*12 screw and M8 flange nut, a total of 16;
2. Mounting base: The base is installed in the lower part of the frame. The base is slotted. The side of the column is embedded in the slot. It is fixed with M8*12 screw and M8 flange nut. Be careful not to tighten. After fixing the left and right bases, fix the beam to the base with M5*10 screws, and finally tighten the M8 screws;
3. Mounting casters: Each caster is secured with 4 M5*10 screws.

